

Instructions for wear checks of play equipment

The equipment must be checked for correct operation and safety, especially the points listed below:

Proof of maintenance

Playground

Date of installation


Checks depend on the kind of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.

Intervals for maintenance work and checks generally depend on:

- location
- kind of use
- frequency of use
- possible vandalism

For more details see also „General instructions for maintenance of playgrounds“.

Water Prism
Order No. 10.31000



Bearings

1. Check for smooth motion
2. Check the horizontal bearings for smooth motion however, it should move such that the prism remains in a set position
3. Check the vertical bearing in the stand post for smooth motion, it should move with small play

Filling

4. Check the filling, it must be clear and transparent, bubbles which appear on the inside surfaces (e. g. over night) should disappear within 2 hours

Cleaning of the surface

5. Clean the steel surface with a special stainless steel cleaning agent
6. Clean the perspex with a mild detergent or a special plastic cleaning agent. Never use spirit or turpentine for cleaning

Structural stability

7. Check the attachment to the ground once a year for firmness

Repair not carried out, it is still possible to play on equipment

Repair not carried out, equipment is taken out of action

All work carried out, everything is in order


Maintenance carried out by

For spare parts please turn over!

..... Date

Special notes (e. g. for repairs):

Spare parts
Water Prism
Order No. 10.31000



Please note that the safety level must not be compromised. This is why it is advisable to use **original spare**.

Order No.	Spare part	
10.99915	water prism housing incl. filling	