En-EN 06.03.2023

COPYRIGHT © RICHTER SPIELGERÄTE GMBH

·····		
Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Structural stability	
Date of installation	In order to check for rot at wooden parts and steel feet for corrosion, uncover the founda- tions once a year.	
Checks depend on the type of equipment. Any equipment with moving parts must	Single equipment	
be checked at least twice a year, static equipment at least once a year.	Single equipment Please pay attention to the separate	
Intervals for maintenance work and checks	maintenance notes of the following single equipment:	
generally depend on - location	Order No. Platform Hut, h=0.50/1.50 m 3.13100	
usagefrequency of use	Sand Play Equipment 3.19100	
- possible vandalism	Climbing Trunk with handrail 3.69516	
For more details see also our general instructions for maintenance of	Firemen's Pole 3.69480	
playgrounds!	Note: Please check that all documents are included!	
Hut Combination 211 Order No. 2.12111		Special notes, e.g. for repairs
	Repair not carried out, it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:	
Date		