

Instructions for wear checks of play equipment

Playground.....

Date of installation


Checks depend on the type of equipment.
Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.

Intervals for maintenance work and checks generally depend on

- location
- usage
- frequency of use
- possible vandalism

For more details see also our general instructions for maintenance of playgrounds!

Hut Combination 213
Order No. 2.12131



The equipment must be checked for correct operation and safety, especially the points listed below:

Structural stability

In order to check for rot at wooden parts and steel feet for corrosion, uncover the foundations once a year.

Single equipment

Please pay attention to the **separate maintenance notes** of the following single equipment:

	Order No.	
Small Platform Hut, h=1.00 m with roof and fittings	3.14350	<input type="checkbox"/>
Fall protection	3.13161	<input type="checkbox"/>
Fastening Frame for attaching Bridge	3.66364	<input type="checkbox"/>
Climbing Rope	3.69433	<input type="checkbox"/>
Bridge 2.00 m with wooden handrail	3.66425	<input type="checkbox"/>
End frame for ramps with wooden handrail	3.66416	<input type="checkbox"/>

Note: Please check that all documents are included!

Proof of maintenance

Special notes, e.g. for repairs

Repair not carried out, it is still possible to play on equipment

☐

Repair not carried out, equipment is taken out of action

☐

All work carried out, everything is in order

☐

Maintenance carried out by:

..... Date