info@ludocrea.ch

6074 Giswil

LudoCrea.ch GmbH

Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Structural stability	
Date of installation Checks depend on the type of equipment.	In order to check for rot at wooden parts and steel feet for corrosion, uncover the foundations once a year.	
Any equipment with moving parts must be checked at least twice a year, static	Single equipment	
equipment at least once a year. Intervals for maintenance work and checks	Please pay attention to the separate maintenance notes of the following single equipment:	
generally depend on	Order No.	
- location	Platform Hut, h=0.50/1.50 m 3.13100	
- usage - frequency of use	Slide with fastening frame 3.19210	
- possible vandalism	Inclined Wall 3.67531	
For more details see also our general instructions for maintenance of playgrounds!	Note: Please check that all documents are included!	
Hut Combination 216 Order No. 2.12160	Repair not carried out,	Special notes, e.g. for repairs
	it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:)