

Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground.....	Wooden parts	<input type="checkbox"/>
Date of installation	<ol style="list-style-type: none"> 1. Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. 	<input type="checkbox"/>
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	<ol style="list-style-type: none"> 2. Check that all bolts and screws are tight and retighten if necessary. 	<input type="checkbox"/>
Intervals for maintenance work and checks generally depend on <ul style="list-style-type: none"> - the location - the usage - the frequency of use - possible vandalism 	<ol style="list-style-type: none"> 3. Check the ash wood rungs of the ladders for wear and tear, the remaining diameter must be at least 30 mm. 	<input type="checkbox"/>
	<ol style="list-style-type: none"> 4. Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre. 	<input type="checkbox"/>
For more details see also "General instructions for maintenance of playgrounds".	Structural stability	
Hexagonal Hut with roof Order No. 3.16300/3.16350	<ol style="list-style-type: none"> 5. In order to check the steel feet for corrosion, uncover the foundation once a year. 	<input type="checkbox"/>
		

