Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Wooden parts	
Date of installation Checks depend on the type of equipment.	Check for rot and, if necessary, smooth out splinters and round off sharp edges and cracks.	
Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	Check all bolts and screws are tight and retighten if necessary.	
Intervals for maintenance work and checks generally depend on	3. Check the ash wood rungs of the ladder for wear and tear, the remaining diameter must be at least 30 mm.	
the locationthe usagethe frequency of usepossible vandalism	Kit room	
For more details see also "General instructions for maintenance of playgrounds".	4. Check door for function and tight fit	
	Window	
Hexagonal Tower with lockable kit room Order No. 3.20900	Check glazing (VSG 8 mm) for intactness and tight fit	
	Structural stability	
	Uncover the foundation once a year in order to check the steel feet for corrosion.	
5		Special notes, e.g. for repairs
	Repair not carried out, it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
6	All work carried out, everything is in order	
	Maintenance carried out by: Date	
	Date	