nstructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground Date of installation Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year. Intervals for maintenance work and checks generally depend on the location the usage the frequency of use possible vandalism For more details see also "General instructions for maintenance of olaygrounds". End frame with ladder or Suspension Bridge Drder No. 3.66033	 Wooden parts Check for rot and, if necessary, smooth splinters and sharp edges for cracks. Check that all bolts and screws are tight and re-tighten if necessary. Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to order No. 0.90100, 1 litre. Check the ash wood rungs of the ladder for wear and tear, the remaining diameter must be at least 30 mm. Structural stability In order to check the steel feet for corrosion, uncover the foundations once a year. 	Special notes, e.g. for repairs
-	Repair not carried out, it is still possible to play on equipment Repair not carried out,	
-	equipment is taken out of action	
	All work carried out, everything is in order	
-		