Instructions for wear The equipment must be checked for Proof of correct operation and safety, especially maintenance checks of play equipment the points listed below: Wooden parts Playground 1. Check for rot and, if necessary, smooth Date of installation splinters and round off sharp edges and cracks. Checks depend on the type of equipment. Any equipment with moving parts must 2. Check that all bolts and screws are tight and be checked at least twice a year, static retighten if necessary. equipment at least once a year. 3. Recommendation: Apply paraffin wax to the Intervals for maintenance work and checks generally depend on upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre. - location - kind of use - frequency of use - possible vandalism For more details see also "General instructions for maintenance of playgrounds". Frame for chain handrail Bridge to Platforms info@ludocrea.ch Order No. 3.66370 675 03 67 Special notes, e.g. for repairs 4 +4] Giswil 6074 (Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action .udoCrea.ch GmbH All work carried out, everything is in order Maintenance carried out by:

...... Date