# Instructions for wear checks of play equipment

The equipment must be checked for correct operation and safety, especially the points listed below:

Proof of maintenance

## Playground .....

#### Date of installation .....


Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.

Intervals for maintenance work and checks generally depend on

- location
- kind of use
- frequency of use
- possible vandalism

For more details see also "General instructions for maintenance of playgrounds".

**End Frame** with chain handrails for Ramp to Huts



#### Wooden parts

- 1. Check for rot and, if necessary, smooth splinters and round off sharp edges and cracks.
- 2. Check that all bolts and screws are tight and retighten if necessary.
- **Recommendation**: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.

#### Chain handrails

4. Check connection to wood, the first chain link must be locked; check wear on contact surfaces between first and second chain link.

### Structural stability

In order to check the steel feet for corrosion. uncover the foundation once a year.

Special notes, e.g. for repairs

info@ludocrea.ch

67

675 03

4 +4]

Giswil

udoCrea.ch GmbH

- Repair not carried out, it is still possible to play on equipment
- Repair not carried out, equipment is taken out of action

All work carried out, everything is in order

Maintenance carried out by:

..... Date .....

RICHTER SPIELGERÄTE D-83112 FRASDORF · PHONE +49-8052/17980 GMBH FAX 4180