Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Wooden parts	
Date of installation	Check for rot and, if necessary, smooth splinters and round off sharp edges of cracks.	
Checks depend on the type of equipment.  Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	<ol> <li>Check all bolts and screws are tight and retighten if necessary.</li> <li>Recommendation: Apply paraffin wax to the</li> </ol>	
Intervals for maintenance work and checks generally depend on	upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.	
- location	Structural stability	
<ul><li>kind of use</li><li>frequency of use</li><li>possible vandalism</li></ul>	In order to check steel bracing for corrosion, uncover the foundation once a year.	
For more details see also "General instructions for maintenance of playgrounds".		
Support Frame for Rope Bridge Order No. 3.66623/3.66633		
2		notes, e. g. for repairs
4		Special notes,
	Repair not carried out, it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:	-
Dat		