Instructions for wear checks of play equipment		The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
Playground		Wooden parts			
Date of installation	1.	Check for rot and, if necessary, smooth splinters and round off sharp edges of cracks.			
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static	2.	Check all bolts and screws are tight and retighten if necessary.			
equipment at least once a year. Intervals for maintenance work and checks generally depend on	3.	Recommendation: Apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.			
- location		Structural stability			
kind of usefrequency of usepossible vandalism	4.	In order to check steel bracing for corrosion, uncover the foundation once a year.			
For more details see also "General instructions for maintenance of playgrounds".					
Support Frame for Rope Bridge to Huts Order No. 3.66645					
1 2				Special notes, e. g. for repairs	
	Rep	pair not carried out, it is still possible		Spec	
		lay on equipment			
		air not carried out, ipment is taken out of action			
		work carried out, rything is in order			
	Mai	ntenance carried out by:			