

Proof of maintenance


5. In order to check for rot at wooden parts or steel feet for corrosion, uncover the foundation once a year.

Maintenance carried out by:

..... Date

Special notes, e.g. for repairs

Spare Parts
Balancing Rope
with Holding Rope
Order No. 3.69010/L3.69010



Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts.**

Order No. Spare part

0.92190 hanging rope with fastening on both sides, length 2,89 m

