Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground Date of installation	Wooden parts 1. Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. 2. Check the screw and bolt connections to the base equipment for firmness, thighten if necessary. Climbing Net 3. Check that connection points are tight and retighten if necessary (see detailed diagram). 4. Check for wear and tear. Replace if steel reinforcement is damaged.	
Inclined Climbing Net for Pyramid Towers, height = 1.00 m Order No. 3.69145/3.69146	 5. if necessary re-tension the net at the bottom ends. Structural stability 6. Uncover the foundation once a year and check the connection (tensioning hook) to the anchoring chain. 	Special notes, e.g. for repairs
detailed diagram	Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action All work carried out, everything is in order	
3	Maintenance carried out by:	