info@ludocrea.ch

6074 Giswil

LudoCrea.ch GmbH

Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.      Check that all bolts and screws are tight and retighten if necessary.      Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.  Fixation of handrails  4. Check connection of handrail chains to	
- possible vandalism  For more details see also our general instructions for maintenance of playgrounds!  Climbing Trunk with double-sided handrail Order No. 3.69521 height 2.00 m  made of square timber	wood and retighten screws and bolts if necessary.  5. Check handrail chains and fixations of handrails: the first chain link of a chain must be locked; check wear on contact surfaces between first and second chain link.  Structural stability  6. In order to check steel feet for corrosion, uncover the foundations once a year.	
Order No. K3.69521		Special notes, e.g. for repairs
	Repair not carried out, it is still possible to play on equipment  Repair not carried out, equipment is taken out of action  All work carried out, everything is in order	
	Maintenance carried out by:	