Instructions for wear checks of play equipmer

Playground.....

Date of installation


Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.

Intervals for maintenance work and checks generally depend on

- the location
- the usage
- the frequency of use
- possible vandalism

For more details see also "General instructions for maintenance of playgrounds".

Big Chicken with net Order No. 4.08200



	Wooden parts	
1.	Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.	
2.	Check that all bolts and screws are tight and retighten if necessary.	
3.	If required, touch up or renew the paintwork using a solvent-free acrylic paint.	
4.	Recommendation : apply paraffin wax to the upper end grain areas once a year, please refer to order No. 0.90100, 1 litre.	
	Net	
5.	Check connection to side walls, retighten screws/bolts if necessary.	
6.	Check for wear and tear. Replace if steel reinforcement is damaged.	
	Structural stability	
7.	In order to check the stability of the foundation or the steel feet for corrosion, uncover the foundation once a year.	
		Special notes, e.g. for repairs
	pair not carried out, s still possible to play on equipment	
	pair not carried out, uipment is taken out of action	
All	work carried out,	