Instructions for wear Proof of The equipment must be checked for maintenance correct operation and safety, especially checks of play equipment the points listed below: Wooden parts Playground..... 1. Check for rot and, if necessary, smooth out Date of installation splinters and round off sharp edges . Checks depend on the type of equipment. Check that all bolts and screws are tight and Any equipment with moving parts must retighten if necessary. be checked at least twice a year, static equipment equipment at least once a year. If required, touch up or renew the paintwork using a solvent-free acrylic paint. Intervals for maintenance work and checks generally depend on **Recommendation**: apply paraffin wax to the upper end grain areas once a year, please - location refer to order No. 0.90100, 1 litre. - usage - frequency of use - possible vandalism Attached parts For more details see also "General 5. Check that sand shovels (2) are complete instructions for maintenance of and check that all elements are securely playgrounds". connected. Structural stability **Small Fish** with Peepholes 6. In order to check for corrosion, uncover the info@ludocrea.ch Order No. 4.08503 foundation once a year. 2 675 03 Special notes, e.g. for repairs **(5**) 4 +4] Giswil Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action .udoCrea.ch GmbH All work carried out, everything is in order Maintenance carried out by: Date