

Proof of maintenance

5. In order to check the steel feet for corrosion, uncover the foundation once a year.

Special notes, e.g. for repairs

..... Date