



Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance	
Playground..... Date of installation Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year. Intervals for maintenance work and checks generally depend on - location - usage - frequency of use - possible vandalism For more details see also our general instructions for maintenance of playgrounds! Up and Down 01 Order No. 4.21210  Up and Down 02 Order No. 4.21250  For spare parts refer to next page.	Wooden parts - Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. ☐ Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre. ☐ Ropes - Check the connections of the ropes for damage and ensure they are secure; tighten if necessary. ☐ - Check ropes for wear and tear, if the steel reinforcement is damaged, it is imperative it be replaced. ☐ Structural stability - Uncover the foundation twice a year in order to check for rot. ☐ Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action All work carried out, everything is in order Maintenance carried out by: Date	Special notes, e.g. for repairs	