En-EN 21.04.2023

COPYRIGHT © RICHTER SPIELGERÄTE GMBH

	The emission of must be abacked for	Proof of			
Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	maintenance			
Playground	Wooden parts				
Date of installation	 Check for rot and, if necessary, smooth out splinters and round off sharp edges of 				
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	cracks.Check that all bolts and screws are tight and retighten if necessary.				
Intervals for maintenance work and checks generally depend on	3. Recommendation : apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.				
- location - usage	Steel bell				
frequency of usepossible vandalism	 Check that the bell is present and securely connected, retighten screws/bolts if necessary. 				
For more details see also our general instructions for maintenance of	Structural stability				
playgrounds!	 In order to check for rot at wooden parts and steel feet for corrosion, uncover the foundations once a year. 				
RIKO Railway Order No. 4.24120/4.24121					
		repairs			
Locomotive Order No. 4.24122		Special notes, e.g. for repairs			
Rail Tender Order No. 4.24123		Special no			
Wagon with Seats Order No. 4.24124	Repair not carried out, it is still possible to play on equipment				
	Repair not carried out, equipment is taken out of action				
	All work carried out, everything is in order				
	Maintenance carried out by:				
	Date				

Spare pa RIKO Railv Order No.	rts way 4.24120/4.2412	21	_ி must no	note that the safety t be affected. Ther t is helpful to only	efore, when carry	/ing out
Order No.	Spare parts					
0.92070	Brass bell					
99.01264	Roller					
				· PHONE +4		