


Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance	
Playground..... Date of installation Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year. Intervals for maintenance work and checks generally depend on - location - kind of use - frequency of use - possible vandalism For more details see also "General instructions for maintenance of playgrounds". "Peter" Horse-cart Order No. 4.24140 	Wooden parts 1. Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. ☐ 2. Check that all bolts and screws are tight and retighten if necessary. ☐ Rein chain 3. Check for wear and tear. ☐ Structural stability 4. Examine by rocking the equipment once a year. ☐	Special notes, e.g. for repairs	
	Repair not carried out, it is still possible to play on equipment		
	Repair not carried out, equipment is taken out of action		
	All work carried out, everything is in order		
Maintenance carried out by: Date			