En-EN 20.12.2023

COPYRIGHT © RICHTER SPIELGERÄTE GMBH

Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Wooden parts	
Date of installation Checks depend on the type of equipment.	 Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. 	
Any equipment with moving parts must be checked at least twice a year, static	Leaf spring and chain	
equipment at least once a year.	2. Check for wear and tear.	
Intervals for maintenance work and checks generally depend on	3. Check the connections of the retaining chain.	
locationusagefrequency of usepossible vandalism	4. Ensure that the leaf spring can swing freely. If the spring is clamped in the floor structure, may it break!	
For more details see also our general	Structural stability	
instructions for maintenance of playgrounds!	5. Examine the foundation by rocking the equipment once a year.	
<section-header></section-header>		Special notes, e.g. for repairs
	Repair not carried out, it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:	
	Date	

Spare parts Swinging Horse Order No. 4.24150		Please note that the safety standards of the equipmen must not be affected. Therefore, when carrying out repairs it is helpful to only use original parts .	
Order No.	Spare parts		
0.88700	Head with handles		
0.88800	Head without handles		
0.88900	Horse body without leaf spring		
0.88910	Horse body without head		
0.92200	Leaf spring with stopper chain		
0.92210	Pair of handles		
99.00160	Tail		

info@ludocrea.ch

I

6074 Giswil