


Instructions for wear checks of play equipment		The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
Playground..... Date of installation Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year. Intervals for maintenance work and checks generally depend on - location - usage - frequency of use - possible vandalism For more details see also our general instructions for maintenance of playgrounds! Dancing Mice Order No. 4.24250 		Wooden parts - Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. - Check that all bolts and screws are tight and retighten if necessary. Recommendation: apply environmentally-friendly wax to the edges of the plywood boards twice a year. - If required, touch up or renew paintwork. Turning mechanism - Check that the mechanism moves smoothly. Ropes - Check that ropes are securely connected. - Replace if steel reinforcement is damaged. Structural stability - Examine the foundation by rocking the equipment once a year.		Special notes, e.g. for repairs	
Repair not carried out, it is still possible to play on equipment		☐			
Repair not carried out, equipment is taken out of action		☐			
All work carried out, everything is in order		☐			
Maintenance carried out by: Date					