Instructions for wear The equipment must be checked for Proof of correct operation and safety, especially maintenance checks of play equipment the points listed below: Wooden parts Playground 1. Check for rot and, if necessary, smooth out Date of installation splinters and round off sharp edges of cracks. Checks depend on the type of equipment. Check that all bolts/screws are tight and Any equipment with moving parts must retighten if necessary. be checked at least twice a year, static equipment twice a year. Recommendation: apply paraffin wax to the upper end grain areas once a year, please Intervals for maintenance work and checks generally depend on refer to Order No. 0.90100, 1 litre. **Operation** - location - kind of use Check all functional parts and retighten bolts/ - frequency of use screws, if necessary. - possible vandalism Bearings and chains For more details see also "General instructions for maintenance of Make sure that bearings and chains move playgrounds". smoothly and check for wear and tear. Sand Transport System Sand container Type I info@ludocrea.ch Order No. 5.06100 Check for wear and tear as well as for vandalism, replace if necessary. Structural stability 7. In order to check for rot at wooden parts or steel feet for corrosion, uncover the foundation once a year. 67 675 03 Special notes, e.g. for repairs 4 +4] Giswil Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action .udoCrea.ch GmbH All work carried out, everything is in order Maintenance carried out by: Date