Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Function	
Date of installation	Make sure the pump mechanism moves smoothly.	
Checks depend on the type of equipment. Any equipment with moving parts must	Intake Container	
be checked at least twice a year, static equipment at least once a year. Intervals for maintenance work and checks	Check water hoses for wear and tear; replace if necessary. To do this, loosen lid bolts and remove upper part including	
generally depend on - location	pump mechanism.3. Check the float valve for leakage, clean reservoir if necessary.	
usagefrequency of use	Cleaning the jet	
- possible vandalism For more details see also our general instructions for maintenance of playgrounds!	4. Use a screwdriver to screw off the jet (spraying head), loosen the connecting hose, clean the jet (pipe cleaners are most suitable), re-connect and screw on.	
A	Structural stability	
Splash Pump with fixed water jet Order No. 5.18050	5. Check anchoring to the ground every 12 months, retighten screws and bolts if necessary.	
Splash Pump with mushroom head Order No. 5.18060	Note Prior to the start of the frost period, turn off water supply, remove the splash pump and drain the intake container. Open the drainage bolt inside the reservoir to do this. If the splash pump has been removed, you may close the opening using a winter lid.	epairs
Intake Container Order No. 5.18052		Special notes, e.g. for repairs
Foundation anchor	Repair not carried out, it is still possible to play on equipment	
Order No. 5.18054	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:	1
For spare parts refer to next page.		
• •		

— info@ludocrea.ch
6074 Giswil—
LudoCrea.ch GmbH —

Spare parts Splash Pump Order No. 5.18050 / 5.18060	Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to only use original parts .	
Order No. Spare parts	Order No.	Spare parts
0.55200 Piston for Splash Pump		
5.18052 Winter lid		