


Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance		
Playground..... Date of installation Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year. Intervals for maintenance work and checks generally depend on - the location - the usage - the frequency of use - possible vandalism For more details see also "General instructions for maintenance of playgrounds". Forest Fountain Low Collision Disc Order No. 5.27030/5.27530 	If the two water jets meet in the right way, the water forms a disc with a spraying edge that varies depending on the water pressure. If the brass spraying heads are clogged, they can be removed (ratchet socket M24) for cleaning. This opportunity should be used to rinse the supply lines by operating the pump. Afterwards, screw in the brass spraying heads (make sure you return each head to its original side). Structural stability Check the mast for rot at wooden parts or corrosion twice a year.	Special notes, e.g. for repairs		
Repair not carried out, it is still possible to play on equipment	☐			
Repair not carried out, equipment is taken out of action	☐			
All work carried out, everything is in order	☐			
Maintenance carried out by: Date				