Instructions for wear checks of play equipment

The equipment must be checked for correct operation and safety, especially the points listed below:

Proof of maintenance

info@ludocrea.ch

675 03

+41 41

Giswil

.udoCrea.ch GmbH

Special notes, e.g. for repairs

Playground.....

Date of installation


Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.

Intervals for maintenance work and checks generally depend on

- the location
- the usage
- the frequency of use
- possible vandalism

For more details see also "General instructions for maintenance of playgrounds".

River Fork Order No. 5.28040



Plate

- 1. Check that plate moves smoothly.
- 2. Check that plate is securely fastened to the pivot axis (Allen key 6 mm).
- 3. Check underside for damage.
- 4. Check the gap between the plate and the ground sheet and remove jammed pieces (gravel or similar) if necessary.

Anchoring to the ground

5. Check that equipment is securely anchored.

Note

In order to extend the durability of the equipment, we recommend removing the equipment parts that are covered with soft plastic (PUR) for the winter.

Repair not carried out, it is still possible to play on equipment	
Repair not carried out,	

Equipment is taken out of action	
All work carried out, everything is in order	

Maintenance carried out by:		
	Date	