# Instructions for wear checks of play equipment

The equipment must be checked for correct operation and safety, especially the points listed below:

Proof of maintenance

# Playground.....

#### Date of installation .....


Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment equipment at least once a year.

Intervals for maintenance work and checks generally depend on

- the location
- the usage
- the frequency of use
- possible vandalism

For more details see also "General instructions for maintenance of playgrounds".

## Raft Order No. 5.45000



### Wooden parts

- 1. Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.
- 2. Check that all bolts and screws are tight and retighten if necessary.
- 3. Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to order No. 0.90100, 1 litre.
- 4. Ensure that punting pole is there, replace if necessary.

2
for re
e.g.
notes,
Special

info@ludocrea.ch

675 03

+4]

Giswil

.udoCrea.ch GmbH

Repair not carried out, it is still possible to play on equipment

Repair not carried out, equipment is taken out of action

All work carried out, everything is in order

Maintenance	carried	out	by:
			_

 Date