Instructions for wear checks of play equipment	СО	The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
Playground		Wooden parts			
Date of installation	1.				
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	2.				
Intervals for maintenance work and checks generally depend on	3.	Recommendation : apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.			
- location - kind of use		Ropes and rope nets			
frequency of usepossible vandalism	4.				
For more details see also "General instructions for maintenance of	5.	Wooden parts 1. Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. 2. Check that all bolts/screws and all wood connections are tight and retighten if necessary. 3. Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre. Ropes and rope nets 4. Check for wear and tear, if worn heavily, it is imperative they be replaced. 5. Check connections and swages. Structural stability 6. In order to check for rot at wooden parts or steel feet for corrosion, uncover the foundations once a year. Vocable Vocab			
playgrounds".					
Climbing Structure 12 Order No. 6.51012/L6.51012	6.	or steel feet for corrosion, uncover the		-	
				1	
				al notes,	
	ı	· · · · · · · · · · · · · · · · · · ·		-	
	Ма	pair not carried out, s still possible to play on equipment pair not carried out, special notes, e.g. for repairs Comparison			
		Date			