info@ludocrea.ch

6074 Giswil

LudoCrea.ch GmbH

Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Wooden parts	
Date of installation	 Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. Check that all wood connections are tight and retighten if necessary. Shorten protruding threads if any and re-galvanise using galvanising spray. Swing suspension Make sure that the joints move smoothly. Make sure that the swivels move smoothly, apply grease if required. Check welds of metal cross beam for cracks. 	
Extra High Swing special Order No. 7.14120	 Check chain and connection to chain, the first chain link must be locked; check wear on contact surfaces between first and second chain link. Swing seats Replace if metal parts are exposed. Check the swing seats for a ground clearance of 55 cm. Structural stability Inordertochecksteel feet for corrosion, uncover the foundations once a year. 	Special notes, e.g. for repairs
	Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:Date	

Spare pa Extra Hig Order No	h Swing special	Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to only use original parts.
Order No. Spare parts		
0.93050	Rubber swing seat for adults	
0.93060	Rubber swing seat with chains for adults	
0.87100	Pair of chains, 6 mm length 3.80 m	