info@ludocrea.ch

6074 Giswil

LudoCrea.ch GmbH

Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Wooden parts	
Date of installation	Check for rot and, if necessary, smooth out splinters and round off sharp edges of	
Checks depend on the type of equipment.  Any equipment with moving parts must	cracks.	
be checked at least twice a year, static equipment at least once a year.	Check that all bolts and screws are tight and retighten if necessary.	
Intervals for maintenance work and checks generally depend on	3. <b>Recommendation</b> : apply wood preservative wax (www.complex-farben.eu) once a year.	
<ul><li>location</li><li>usage</li></ul>	Stainless steel	
<ul><li>frequency of use</li><li>possible vandalism</li></ul>	Clean with stainless steel spray (www.kim-tec.de) using a clean cloth.	
For more details see also our general instructions for maintenance of	Joints	
playgrounds!	5. Check for mobility, clean if necessary.	
Island Seat 01	Structural stability  6. Uncover the foundation once a year in	
with 3 movable backs Order No. 7.83150	order to check that the equipment is properly anchored to the ground.	
Island Seat 02 with 2 movable backs		Special notes, e.g. for repairs
Order No. 7.83152		Special
3 1	Repair not carried out, it is still possible to play on equipment	
4	Repair not carried out, equipment is taken out of action	
2	All work carried out, everything is in order	
6	Maintenance carried out by:	
	Date	