Instructions for wear The equipment must be checked for correct operation and safety, especially Proof of maintenance checks of play equipment the points listed below: Concrete Playground..... 1. Check for vandalism, e.g. broken concrete Date of installation edges and, if necessary, carefully sand down Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year. Cleaning Intervals for maintenance work and checks 2. If the concrete surface is soiled, clean using generally depend on: sponge and warm water - the location 3. Treat efflorescence by applying a mixture of - the usage acetic acid and water with the ratio 1:3 - the frequency of use - possible vandalism **Note** To prevent graffiti attacks, the concrete For more details see also "General surface can be treated with Protectosil instructions for maintenance of (www.protectosil.com) playgrounds". Wooden parts Curve 4. Check for rot and, if necessary, smooth out Order No. 7.89500 info@ludocrea.ch splinters and round off sharp edges of cracks 5. Check that all bolts and screws are tight and **Bench** made of Larch retighten if necessary Order No. 7.89550 **Recommendation**: apply paraffin wax to the upper end grain areas once a year, please refer to order No. 0.90100, 1 litre Structural stability 67 675 03 Special notes, e.g. for repairs Check for a proper and stable stand 4 +4] Giswil Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action .udoCrea.ch GmbH All work carried out, everything is in order Maintenance carried out by: Date