nstructions for wear checks of play equipment	со	The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
Playground		Wooden parts			
Date of installation	1.	Check for rot and, if necessary, smooth splinters and round off sharp edges and cracks.			
Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	2.				
Intervals for maintenance work and checks generally depend on		Structural stability			
	3.	Check fixation to the ground once a year by			
<ul> <li>location</li> <li>kind of use</li> <li>frequency of use</li> <li>possible vandalism</li> </ul>		lifting.			
For more details see also "General Instructions for maintenance of playgrounds".					
Phones in Wood Order No. 9.02700/9.02720					
				for repairs	
(3)				Special notes, e.g. for repairs	
		pair not carried out, s still possible to play on equipment			
		pair not carried out, uipment is taken out of action			
	-				
		work carried out, erything is in order			