Instructions for wear checks of play equipment

The equipment must be checked for correct operation and safety, especially the points listed below:

Proof of maintenance

Playground.....

Date of installation


Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment equipment at least once a year.

Intervals for maintenance work and checks generally depend on

- the location
- the usage
- the frequency of use
- possible vandalism

For more details see also "General instructions for maintenance of playgrounds".

Distorting Mirror with stainless steel posts Order No. 9.10700



Wooden parts

- 1. Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.
- 2. Check that all bolts and screws are tight and retighten if necessary.
- Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to order No. 0.90100, 1 litre.

Mirror

4. Clean with mild detergent using a clean cloth.

Stainless steel

5. Clean with stainless steel spray (www.kimtec.de) using a clean cloth.

Structural stability

6. In order to check the anchoring for corrosion, uncover the foundations once a year.

for repairs
for
e.g.
notes, e.g. f
_

info@ludocrea.ch

+41

Giswil

6074

udoCrea.ch GmbH

Repair not carried out, it is still possible to play on equipment

Repair not carried out, equipment is taken out of action

All work carried out, everything is in order

Maintenance carried out by:

\mathbf{r}	-	4-	
	-	ТΔ	

RICHTER SPIELGERÄTE GMBH · D-83112 FRASDORF · PHONE +49-8052/17980 · FAX 4180