Instructions for wear checks of play equipment

Playground.....


Date of installation

Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.

Intervals for maintenance work and checks generally depend on

- the location
- the usage
- the frequency of use
- possible vandalism

For more details see also "General instructions for maintenance of playgrounds".



The equipment must be checked for correct operation and safety, especially the points listed below:

Proof of

maintenance

info@ludocrea.ch

67

675 03

4 +4]

Giswil

6074

.udoCrea.ch GmbH

Special notes, e.g. for repairs

Playground equipment

- 1. Check that playing tokens are complete (red x 21, blue x 21) und make sure they move smoothly.
- 2. Check that the bolts and screws on the back and on the stand posts are tight and retighten if necessary.

Stainless steel

3. Clean with stainless steel spray (www.kim-tec.de) using a clean cloth.

Structural stability

4. In order to check the fixation to the ground, uncover the foundations once a year.

En-EN

Maintenance carried out by:

Repair not carried out,

Repair not carried out,

All work carried out, everything is in order

it is still possible to play on equipment

..... Date

equipment is taken out of action