## Instructions for wear The equipment must be checked for Proof of correct operation and safety, especially checks of play equipment maintenance the points listed below: Wooden parts Playground..... 1. Check for rot and, if necessary, smooth out Date of installation ..... splinters and round off sharp edges of cracks. Checks depend on the type of equipment. Check all the screw and bolt connections for Any equipment with moving parts must firmness, tighten if necessary. be checked at least twice a year, static equipment equipment at least once a year. 3. Check that the tracks are securely connected to the steel posts (check for wear and tear) Intervals for maintenance work and checks generally depend on and replace if necessary. - the location **Functional parts** - the usage - the frequency of use - possible vandalism 4. Check all functional parts and retighten screws and bolts, if necessary. For more details see also "General instructions for maintenance of Structural stability playgrounds". 5. In order to check the fixation to the ground, uncover the foundation once a year. **Ball Track** Order No. 9.19100/9.19200/9.19500 info@ludocrea.ch Metal parts and fittings 6. File down any sharp edges that may arise from wear and tear. 675 03 Special notes, e.g. for repairs +4] Giswil Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action .udoCrea.ch GmbH All work carried out, everything is in order Maintenance carried out by: ..... Date ......