Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance	
Playground	Wooden parts		
Date of installation	Check for rot and, if necessary, smooth out splinters and round off sharp edges of		
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	cracks. 2. Check that all bolts and screws are tight and retighten if necessary.		
Intervals for maintenance work and checks generally depend on	3. Check the ash wood rungs of the ladders for wear and tear, the remaining diameter must be at least 30 mm.		
locationusagefrequency of use	4. Recommendation : apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.		
- possible vandalism	Structural stability		
For more details see also our general instructions for maintenance of playgrounds!	5. In order to check for rot at wooden parts and steel feet for corrosion, uncover the foundations once a year.		
Pentagonal Tower with ladder and roof Order No. L3.20750 height 1.50 m Order No. L3.20800 height 2.00 m	Donais not considered out	Special notes, e.g. for repairs	
5	Repair not carried out, it is still possible to play on equipment		
	Repair not carried out, equipment is taken out of action		
	All work carried out, everything is in order		
For spare parts	Maintenance carried out by:		
refer to back of page.	Date		

Spare parts				
Pentagonal Tower				
Order No. L3.20750/L3.20800				



Spare par Pentagona Order No. I	rts I Tower L3.20750/L3.20800	Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to only use original parts .
Order No.	Spare parts	
0.92620	Ladder	
0.98310	Single rung	