Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Wooden parts	
Date of installation	Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.	
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	Check that all bolts and screws are tight and retighten if necessary.	
Intervals for maintenance work and checks generally depend on	3. Check steps for wear and tear: at least 2/3 of the material should be left, replace if necessary.	
locationusage	Structural stability	
- frequency of use		
- possible vandalism	4. In order to check for rot at wooden parts and steel feet for corrosion, uncover the	
For more details see also our general instructions for maintenance of playgrounds!	foundations once a year.	
Small Timber House on Stilts Order No. L4.10300 Order No. L4.10310 with door		Special notes, e.g. for repairs
	Repair not carried out, it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:	
For spare parts refer to back of page.	Date	
i or spare parts refer to back or page.		

Spare parts				
Small Timber House on Stilts				
Order No. L4.10300/L4.10310				



Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out

Small Timber House on Stilts Order No. L4.10300/L4.10310		must not be affected. Therefore, when carrying out repairs it is helpful to only use original parts .
Order No.	Spare parts	
0.30021 Roof cladding, larch	Roof cladding, larch	
	Please indicate the covering surface!	
99.01364 Stan	Stand post, larch	