info@ludocrea.ch

6074 Giswil

LudoCrea.ch GmbH

Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Wooden parts	
	Wooden parts	
Date of installation	Check for rot and, if necessary, smooth out splinters and round off sharp edges of	
Checks depend on the type of equipment.	cracks.	
Any equipment with moving parts must		
be checked at least twice a year, static	2. Check that all bolts and screws as well as	
equipment at least once a year.	all wood joints are tight, retighten if neces-	
ntervals for maintenance work and checks	sary.	
generally depend on	3. Check steps for wear and tear: at least 2/3	
generally depend on	of the material should be left, replace if	
location	necessary.	
usage		
frequency of use	Structural stability	
possible vandalism	4. Uncover the foundations once a year in	
or more details see also our general	order to check the structural stability as	
nstructions for maintenance of	follows:	
playgrounds!	<ul><li>wood for rot</li><li>steel for corrosion</li></ul>	
	- anchoring to the ground for stability	
	- condition of concrete foundations	
Laura Craum A		
louse Group A Order No. L4.10700		
order No. L4.10700		
		Special notes, e.g. for repairs
	Repair not carried out, it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:	
For spare parts refer to back of page.	Date	

Spare parts				
House Group A				
Order No. L4.10700				



Please note that the safety standards of the equipment

House Group A Order No. L4.10700		must not be affected. Therefore, when carrying out repairs it is helpful to <b>only use original parts</b> .	
Order No.	Spare parts		
0.30021	Roof cladding, length 1.43 m, larch		
99.01364	Stand post with steel foot, larch		