Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
	IIS	ited below:		
Playground		Wooden parts		
Date of installation	1.	Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.		
Checks depend on the kind of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	2.	Check that all bolts and screws are tight and retighten if necessary.		
Intervals for maintenance work and checks generally depend on:	3.	Recommendation : apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.		
locationkind of use		Joints		
frequency of usepossible vandalism	4.	Check the swivel joints for smooth motion, lightly grease if required.		
For more details see also "General instructions for maintenance of playgrounds".	5.	Check the connection to the wood, collar of joint must be flush.		
playgrounds :		Rope connections/Ropes		
Swing Scales Order No. 6.10200/L6.10200	6.	Check all ropes for signs of wear, renew if the steel core is damaged.		
(2) g (3) (3)	7.	Check the connection of the rope, lightly oil during each maintenance.		
1) (2)		Suspension/Pendulum seats		
5 8 6	8.	Check chains and fastenings to the chains, the first link must be securely jammed, check wear on the next moving link.		
9	9.	Renew the pendulum seats if metal core is visible.		r repairs):
10		Structural stability		e. g. fc
	10	 In order to check for rot at wooden parts or steel feet for corrosion, uncover the foundation once a year. 		Special notes (e. g. for repairs):
	1	pair not carried out, s still possible to play on equipment		
	Repair not carried out, equipment ist taken out of action			
		work carried out, erything is in order		
	Ма	nintenance carried out by		
		Date		