En-EN 29.11.2024

COPYRIGHT © RICHTER SPIELGERÄTE GMBH

Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Wooden parts	
Date of installation	 Check for rot and, if necessary, smooth out splinters and round off sharp edges of 	
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	 cracks. 2. Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre. 	
Intervals for maintenance work and checks generally depend on	Climbing Net	
- location - usage	3. Check for wear and tear. Replace if steel reinforcement is damaged.	
frequency of usepossible vandalism	 Check that connection points are tight and retighten if necessary (see detailed diagram B). 	
For more details see also our general instructions for maintenance of	Firemen's Pole	
playgrounds!	5. Check that bolts and screws are tight and retighten if necessary.	
Vertical Climbing Net Order No. L6.51600 / K6.51600	Structural stability	
with bent firemen's pole	 In order to check steel feet for corrosion, uncover the foundations once a year. 	
Order No. L6.51630 / K6.51630 without firemen's pole		
2		
		Special notes, e.g. for repairs
detailed diagram	Repair not carried out, it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:	
For spare parts refer to next page.	Date	

Spare parts Vertical Climbing Net Order No. L6.51600 / K6.51600		Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to only use original parts .	
Order No.	Spare parts		
0.98055	Vertical Climbing Net		
99.01301	Stand posts for firemen's pole made of larch		