




Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance	
Playground Date of installation Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year. Intervals for maintenance work and checks generally depend on - location - kind of use - frequency of use - possible vandalism For more details see also "General instructions for maintenance of playgrounds". Climbing Ropes double element Order No. L6.51825  detailed diagram  For spare parts refer to back of page.	Wooden parts 1. Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. ☐ 2. Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre. ☐ Ropes 3. Check ropes for wear and tear, if the steel reinforcement is damaged it is imperative it be replaced. ☐ 4. Check chain connections and swages are tight (see detailed diagram). ☐ Structural stability 5. In order to check for rot at wooden parts or steel feet for corrosion, uncover the foundations once a year. ☐ Repair not carried out, it is still possible to play on equipment ☐ Repair not carried out, equipment is taken out of action ☐ All work carried out, everything is in order ☐ Maintenance carried out by: Date	Special notes, e.g. for repairs	

Spare parts
Climbing Ropes
double element
Order No. L6.51825



Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts**.

Order No. Spare part

- 0.92187 Holding rope with chain attachment**
- 0.92188 Running rope with chain attachment**
- 0.99405 Disc for chain suspension**