

| Instructions for wear checks of play equipment | The equipment must be checked for correct operation and safety, especially the points listed below: | Proof of maintenance |
|---|--|--|
| Playground..... | Wooden parts | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |
| Date of installation Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year. | <ol style="list-style-type: none"> Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. Check that all bolts and screws as well as all wood joints are tight, retighten if necessary. Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre. | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |
| Intervals for maintenance work and checks generally depend on <ul style="list-style-type: none"> - location - usage - frequency of use - possible vandalism | Swing suspension <ol style="list-style-type: none"> Makes sure that the joints move smoothly, apply grease if required. Make sure that the swivels move smoothly, apply grease if required. Check chain and connection to chain, the first chain link must be locked; check wear on contact surfaces between first and second chain link. | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |
| Giraffe Swing | Cross bar | <input type="checkbox"/> |
| Order No. L6.00001 | <ol style="list-style-type: none"> Check that the sand pipe is securely connected and retighten bolts/screws if necessary. | <input type="checkbox"/> |
| | Swing seats | <input type="checkbox"/> |
| | <ol style="list-style-type: none"> Check for vandalism, replace if metal parts are exposed. | <input type="checkbox"/> |
| | Structural stability | <input type="checkbox"/> |
| | <ol style="list-style-type: none"> In order to check steel feet for corrosion, uncover the foundations once a year. | <input type="checkbox"/> |
| | Repair not carried out, it is still possible to play on equipment | <input type="checkbox"/> |
| | Repair not carried out, equipment is taken out of action | <input type="checkbox"/> |
| | All work carried out, everything is in order | <input type="checkbox"/> |
| | Maintenance carried out by: Date | Special notes, e.g. for repairs |