info@ludocrea.ch

6074 Giswil

LudoCrea.ch GmbH

Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance	
Playground	Wooden parts		
Date of installation	Check for rot and, if necessary, smooth out splinters and round off sharp edges of		
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	cracks.  2. Check that all bolts and screws are tight and retighten if necessary.		
Intervals for maintenance work and checks	Swing suspension		
generally depend on	3. Make sure that the joints move smoothly, apply grease if required.		
<ul><li>location</li><li>usage</li><li>frequency of use</li></ul>	Make sure that the swivels move smoothly, apply grease if required.		
- possible vandalism  For more details see also our general	Check welds of metal cross beam for cracks.		
instructions for maintenance of playgrounds!	Check chain and connection to chain, the first chain link must be locked; check wear on contact surfaces between first and second chain link.		
High Swing special long	Swing seat		
as attachment to platforms Order No. 3.19852/K3.19852	Replace swing seat if metal parts are exposed.		
5 3 4 6 7 40 cm 8	8. Check the seat for a minimum ground clearance of 40 cm.		
	Structural stability		
	9. In order to check for rot at wooden parts and steel feet for corrosion, uncover the foundations once a year.  Output  Description:	Special notes, e.g. for repairs	
	Repair not carried out, it is still possible to play on equipment		
	Repair not carried out, equipment is taken out of action		
	All work carried out, everything is in order		
For spare parts refer to back of page.	Maintenance carried out by:		
Terer to back or page.	Date		

## Spare parts High Swing special long Order No. 3.19852/K3.19852



Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts.** 

Order No.	Spare parts	Order No.	Spare parts
0.93000	Rubber swing seat	0.93090	U-shackle with swivel
0.93010	Rubber swing seat with 4 eyebolts	0.88150	Brass bush for swing joint
0.93020	Rubber swing seat with 2 V-chains	0.20010	Stainless steel machine bolt M8x58 with locking nut
0.93021	V-chain	0.20020	Stainless steel machine bolt M8x28 with locking nut
0.00021			and the second of the second o
0.93120	Rubber swing seat with chains		
0.93100	Chains (pair) 6 mm length 2.35 m		