

Proof of maintenance

Check tyre for ground clearance of 40 cm.

11. Check tyres for wear and tear as well as for vandalism; replace if required.
12. Replace fender profile (impact protection) if half of the material has been worn down.

Maintenance carried out by:


..... Date

Special notes, e.g. for repairs



















Spare parts

Car Tyre Swing

Order No. 6.18460



Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts**.

Order No. Spare part	Order No. Spare part
<p>0.93300 universal joint</p> 	<p>0.93460 A-frame without fixing bolt, with steel feet</p> 
<p>0.93310 mounting bracket for universal joint</p> 	<p>0.93461 A-frame without fixing bolt, pre-drilled for existing steel feet</p> 
<p>0.93320 safety cable for universal joint</p> 	<p>0.93470 fender profile for laminated beam</p> 
<p>0.93551 forked bolt for chain fastening</p> 	<p>0.93481 fixing bolt</p> 
<p>0.20020 stainless steel machine bolt</p> 	<p>99.00300 stand post, pre-drilled with steel foot</p> 
<p>0.93505 tyre with floor and 4 chains</p> 	<p>99.01200 stand post, pre-drilled for steel foot</p> 
<p>0.93510 tyre with floor without chains</p> 	<p>99.01265 cross beam for A-frame</p> 
<p>99.01274 floor Ø 60 cm, milled</p> 	
<p>0.93620 chain, at least 1.92 m long</p> 	
<p>0.93400 anchoring iron for laminated beam</p> 	
<p>0.93450 laminated beam with fender profile</p> 	<p>Note This list includes only the spare parts ordered most frequently. Other spare parts on request.</p>