Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Wooden parts	
Date of installation	 Check for rot and, if necessary, smooth out splinters and round off sharp edges of 	
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	 cracks. 2. Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre. 	
Intervals for maintenance work and checks generally depend on	Climbing Net	
 location usage frequency of use possible vandalism 	 Check that connection points are tight and retighten if necessary (see detailed diagram dimension B). Check for wear and tear. Replace if steel reinforcement is damaged. 	
For more details see also our general instructions for maintenance of	Firemen's Pole	
playgrounds!	5. Check that bolts and screws are tight and	
Vertical Climbing Net with bent Firemen's Pole, for attachment	retighten if necessary. Structural stability 6. In order to check steel feet for corrosion,	
Order No. L3.69350 / K3.69350	uncover the foundations once a year.	Special notes, e.g. for repairs
detailed diagram	Repair not carried out, it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:	
For spare parts refer to next page.	Date	

info@ludocrea.ch

6074 Giswil

LudoCrea.ch GmbH

COPYRIGHT © RICHTER SPIELGERÄTE GMBH

	ts nbing Net emen's Pole, for attachment 3.69350 / K3.69350	Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to only use original parts.
Order No.	Spare parts	
0.98055	Vertical Climbing Net	
99.01301	Stand posts for Firemen's Pole, made of larch	